


1.



2.




App

3.



4.



5.




6.

Sensor type
SEPTH



7.



8.




9. (In case of no connection)



10.



max 5 m



Lindab **Wireless Sensor SEPTH**

Installation instruction

